



Towbar Fitting Instructions
To Suit FORD FALCON AU EF EA/B/D/F EL STATION WAGON 8/94-ON
Part Number FD88C
Rating 1600Kg

1. Ensure all hardware items have been included.
2. Fold back carpet to rear seat.
3. Remove bumper bar.
4. Fit towbar to rear chassis, with bolts and small loose plates, ensuring that towbar is central to vehicle.
5. Tighten all bolts to torque listing below.
6. Push out insert in centre of bumper bar.
7. Replace bumper bar and carpet.

NOTE: Two tabs on top of bumper window may have to be taken off for proper fitment.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

