



Towbar Fitting Instructions
To Suit MAZDA 626 SEDAN & HATCH 92-7/97
Part Number MA61
Rating 920Kg

1. Ensure all hardware items have been included.
2. Remove boot panel trim.
3. Remove shipping hook on passenger's side back panel.
4. Remove bumper bar.
5. Use two holes each side on inner side of sub frames; two in boot, two from under car.
6. Line towbar up with holes previously described and support with jack.
7. Fit bolts and plates supplied.
8. Tighten all bolts to torque listing below.
9. Refit bumper bar.
10. Refit boot panel trim.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8



Towbar Fitting Instructions
To Suit MAZDA 626 SEDAN & HATCH 92-7/97
Part Number MA61
Rating 920Kg

