

TRAILBOSS

TOWBAR FITTING INSTRUCTIONS TO SUIT TOYOTA LANDCRUISER 80 SERIES WAGON

PART No QT1090
RATING OF 3500 Kg.

1990-7/1996 - 2500KG

8/96 - 2/98 - 3500KG

1. Offer the Towbar to the vehicle.
2. Loosely secure the Towbar initially, with Items 1, 2, 3, and 4.
3. Using the two rearmost holes in the Towbar side arms as a guide, drill up through the chassis with a 13mm diameter drill.
4. Insert the tapped plate, Item 8, and secure using Items 5, 6, and 7.
5. Tighten all the Bolts to the specified torque.
6. Attach Hitchbox collar (Item 12) to towbar by applying even pressure. Secure tongue to towbar using Hitch pin and "R" pin. (Items 9, 10 and 11).

COMPONENT KIT

ITEM	DESCRIPTION	QTY	TORQUE Nm.
1	M12 x 40 x 1.25 P Bolt.	6	77
2	12mm Spring Washer.	6	
3	12mm Flat Washer.	6	
4	M12 x 1.25 P Nut.	2	
5	7/16" unc. x 1.1/2" Long Bolt.	2	82
6	7/16" Spring Washer.	2	
7	7/16" Flat Washer.	2	
8	7/16" unc. Tapped Plate (Standard)	2	
9	Hitch Pin	1 *	
10	"R" Pin	1 *	
11	Tongue, 5017	1	
12	Trailboss Hitchbox collar	1	

NOTE: Items 9 and 10 are used to secure the tongue to towbar for transit purposes

WIRING CODE

Function	Loom Colour	Vehicle Colour
Left hand turn indicator	Yellow	Green and Black
Earth	White	White and Black
Right hand turn indicator	Green	Green and Yellow
Stop Lamps	Red	Green and White
Tail Lamps	Brown	Green

Issue Date 3-2-97

THE WORKHORSE OF AUSTRALIA'S TOWBARS

*Towbar usage not to exceed Queensland Towbars stated capacity and or vehicle manufacturer's recommended towing capacity, (whichever is the lesser). The fitment of level ride bars or bike racks, will void this warranty. Any replacement or remedial work to be carried out at our head office. All freight costs to borne by sender

