



Towbar Fitting Instructions
To Suit TOYOTA CAMRY SEDAN 8/97- 06/2006 & WAGON 5/98- 06/2006
Part Number TT119A
Rating 1200Kg

1. Ensure all hardware items have been included.
2. Remove and discard both left and right hand shipping hooks.
3. Remove muffler from 2 rearmost hangers and remove rear most rubber hanger.
3. Remove spare wheel.
4. Remove any excessive body deadener from mounting points on vehicle.
5. Lift towbar up into position by feeding driver's side up over exhaust pipe.
6. Align holes in towbar angles with shipping hook bolt holes.
7. Fit 4 M10x35 1.25 pitch bolts, flat washers and spring washers.
8. Using two holes in tail plate as a guide drill two 11mm holes into spare wheel compartment.
9. Fit 2 M10x30 bolts and loose plates as shown in diagram.
10. Tighten all bolts to torque listing below.
11. Refit exhaust to forward most rubber hanger. Refit rear most rubber hanger to rod provided on towbar and to exhaust.
11. Refit spare wheel.

RECOMMENDED ASSEMBLY TORQUE LISTING

| <u>Diameter</u> | <u>Grade 8.8 Bolt</u> |
|-----------------|-----------------------|
| | Nm |
| M6 | 9.5 |
| M8 | 21.7 |
| M10 | 43.4 |
| M12 | 77.3 |
| M14 | 121.0 |
| M16 | 189.8 |

FOR TOWING PURPOSES ONLY

For towing capacity details please refer to vehicle owner's manual or to the manufacturer. Overloading can void your warranties.

TRAILBOSS

Towbar Fitting Instructions
To Suit TOYOTA CAMRY SEDAN 8/97- 06/2006 & WAGON 5/98- 06/2006
Part Number TT119A
Rating 1200Kg

